



Asus X53BR HDD Replacement

Written By: Youfixit






TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — HDD



- Locate the HDD compartment bottom of the laptop

Step 2



- Remove the screw.

Step 3



- Open cover HDD.

Step 4



- Pull the label.
- Remove HDD.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-15 07:11:04 PM.